

LED Wireless Charging Bluetooth Speaker

BT3401



Instructions for using the wireless charging speaker



Wireless charger use: plug in the charger to automatically turn on

- ⏻ Long press power / short press light switch
- ⏸ Long press function switch BT / NS / FM mode, short press pause / play
- ⌚ Short press the timing 15 / 30 / 60, long press the Bluetooth couplet
- ⏭ Short press the next song, long press to add the volume
- ⏮ Short press the last song, long press to reduce the volume
- ⌚ Alarm clock setting
- ⌚ Clock Settings

technical parameter:

Wireless charging power: 15W

Bluetooth version: 5.3

Bluetooth name: BT3401

Output power: 5W

Bluetooth frequency: 2.4GHZ-2.48GHZ

Transmission distance: 10 meters

Frequency sound range: 50 HZ-20 KHZ

Sigto noise ratio of whole machine: greater than 75 db

Built-in lithium battery voltage: 3.7V charging input: DC5V / 500MA

Product size: 235 * 80 * 238mm

Product weight: 770g

Operation description of the key function

- 一、 Start up: long press the start button for two seconds to start up, start up the default heating light
- 二、 The Bluetooth function is used for use:
 1. This audio supports the use of Bluetooth devices with A2DP function, boot default into the Bluetooth mode, Bluetooth indicator blue light shining, accompanied by voice prompt, when the stereo is waiting for pairing connection, only in this state, can be paired and connected with the Bluetooth audio.

2. Mobile phone connection

The first step is to open the phone Bluetooth setting switch in the phone Settings and click the search device

The second step, when the available device displays the BT3401 character indicating that the phone finds the Bluetooth stereo, click BT3401 to enter the pairing mode. After the phone is successfully paired with the stereo, there will be a voice prompt and display the connected.

三、TWS couplet function (this function is suitable for Bluetooth mode only)

When you have two BT3401 Bluetooth speakers, by long pressing one of the keys to match, Bluetooth connected to each other, the two speakers will automatically become the left and right sound channels to produce stereo surround sound effect, achieving real wireless stereo.

Light use

- 1) The BT3401 Bluetooth speaker is equipped with 13 lighting effects
- 2) Start the default warm lamp effect of the equipment, and press the light key to adjust the light

FM radio to use:

M key long press to switch to the FM function, connect the charging cable to the product type-c interface as a radio antenna, the other end does not need to connect any equipment, through the pause button to enter the station automatic search and automatically save, the cable station through + -saved station selection.

TF card / U disk function for use:

By inserting the TF card / U disk into the card slot, the corresponding voice prompt will

appear. The product will automatically read the audio file in the card and play it. The user can use the voice to control the music with the speaker + -button.

Clock Setting

Press the time key to enter the clock / minute setting, press / adjust the hour / minute +/▶▶/–/◀◀

Alarm clock setting

+/▶▶/–/◀◀ Press the alarm button to enter the clock / minute setting, press / adjust the hour / minute, press the alarm key and then press / select your favorite alarm, there are 7 groups of alarm bells, and finally press the alarm key to open the alarm clock (the alarm mark appears on the screen after successful setting). When the alarm rings, press any key to close the alarm.

When no one turns off, the alarm will automatically turn off for 1 minute (the alarm will ring normally in the shutdown state, please cancel the alarm clock without the need)

Cancel alarm setting: long press the alarm key (the alarm sign disappears on the screen after successful cancellation)

White noise use:

M to switch to white noise mode, press / choose your favorite sleep music +/▶▶/–/◀◀

Safety Instructions:

1. Do not expose the product into the water or humid areas, such as bathrooms.
2. Please do not hit or drop the product hard to avoid manual damage.
3. When not in use for a long time, please turn off the power.

Warranty and After Sales Service :

If you have any questions during use, please feel free to contact us, we are responsible for every customer.